




E 501/09/200



POS	CODE	DESCRIPTION
1	8804000000372	HEX SCREW
2	8804000000373	SPRING WASHER
3	8804000000374	FRONT COVER
4	8804000000375	FRONT COVER GASKET
5	8804000000376	BALL BEARING
6	8804000000377	OIL SIGHTGLASS
7	8804000000378	OIL SIGHTGLASS SEAL
8	8804000000379	BREATHER (M16*1.5)
9	8804000000380	CRANKCASE
10	8804000000381	BASEPLATE SEAL
11	8804000000382	BASEPLATE
12	8804000000383	SPRING WASHER
13	8804000000384	HEX SCREW
14	8804000000385	OIL PLUG (G1/8")
15	8804000000386	CRANKSHAFT
16	8804000000387	BALL BEARING
17	8804000000388	BEARING SEAT GASKET
18	8804000000389	OIL SEAL
19	8804000000390	BEARING SEAT
20	8804000000391	SPRING WASHER
21	8804000000392	HEX SCREW
22	8804000000509	FLYWHEEL
23	8804000000394	FLYWHEEL FLAT WASHER
24	8804000000395	FLYWHEEL SCREW
25	8804000000396	HEX SCREW
26	8804000000397	SPRING WASHER
27	8804000000510	CYLINDER GASKET
28	8804000000399	CYLINDER
29	8804000000400	VALVE PLATE GASKET
30	8804000000401	VALVE PLATE
31	8804000000402	VALVE PLATE GASKET
32	8804000000403	VALVE REED
33	8804000000404	VALVE PLATE
34	8804000000405	HEAD COVER GASKET
35	8804000000406	AIR FILTER
36	8804000000407	HEX SCREW
37	8804000000408	HEX SCREW
38	8804000000409	SPRING WASHER

POS	CODE	DESCRIPTION
39	8804000000410	HEAD COVER
40	8804000000411	AFTERCOOLER GASKET
41	8804000000463	AFTERCOOLER
42	8804000000413	SPRING WASHER
43	8804000000414	HEX SCREW
44	8804000000415	CONNECTOR
45	8804000000416	CONNECTOR NUT
46	8804000000464	PISTON PIN
47	8804000000465	COMPRESSOR RING
48	8804000000466	OIL RING
49	8804000000467	PIN CLIP
50	8804000000468	PISTON
51	8804000000422	CONNECTING ROD
52	8804000000469	MOTOR
53	8804000000470	SPRING WASHER
54	8804000000471	SCREW
55	8804000000472	MOTOR POWER CORD
56	8804000000473	PULLEY
57	8804000000474	KEY
58	8804000000475	BELT
59	8804000000430	FLAT WASHER
60	8804000000431	SCREW
61	8804000000476	GUARD
62	8804000000433	PRESSURE GAUGE (50 MM)
63	8804000000434	PRESSURE SWITCH
64	8804000000435	SAFETY VALVE
65	8804000000477	POWER CORD
66	8804000000437	NUT
67	8804000000478	TUBE
68	8804000000479	ELBOW CONNECTOR
69	8804000000480	CHECK VALVE
70	8804000000441	HEX NUT
71	8804000000481	EXHAUST PIPE
72	8804000000443	OBSERVATION HOLE PLUG
73	8804000000482	TANK (200L)
74	8804000000483	U-SHAPE HANDLE
75	8804000000484	HEX NUT
76	8804000000485	FLAT WASHER

POS	CODE	DESCRIPTION
77	8804000000486	WHEEL
78	8804000000487	HEX SCREW
79	8804000000450	DRAIN VALVE
80	8804000000451	UNIVERSAL WHEEL (3")
81	8804000000452	FLAT WASHER
82	8804000000453	SPRING WASHER
83	8804000000454	HEX NUT
84	8804000000455	SCREW
85	8804000000456	FLAT WASHER
86	8804000000457	SPRING WASHER
87	8804000000458	NUT
88	8804000000459	OBSERVATION HOLE PLUG
89	8804000000460	ITALY TYPE REGULATOR
90	8804000000461	PRESSURE GAUGE (40 MM)
91	8804000000462	QUICK CONNECTOR

