


Spare part list silent diesel generator **GSEm 8500 TDE**



GSEm 8500 TDE Explosion diagram



GSEm 8500 TDE Spare parts			
Ser.No	Order code	Description	Reqd. QTY
1	39085200611S001	Engine	1
2	39085200611S002	bolt	4
3	39085200611S003	Nut	4
4	39085200611S004	Generator cover	1
5	39085200611S005	bolt	4
6	39085200611S006	generator	1
6-1	39085200611S0061	Generator rotor	1
6-2	39085200611S0062	Generator stator	1
7	39085200611S007	bolt	1
8	39085200611S008	Flat pad	1
9	39085200611S009	Spring cushion	1
10	39085200611S010	bolt	1
11	39085200611S011	Flat pad	4
12	39085200611S012	Spring cushion	4
13	39085200611S013	/	/
14	39085200611S014	Nut	8
15	39085200611S015	Shock absorber	4
16	39085200611S016	bracket	1
17	39085200611S017	bolt	2
18	39085200611S018	Nut	2
19	39085200611S019	Motor bracket	1
20	39085200611S020	Motor tail cover	1
21	39085200611S021	bolt	3
22	39085200611S022	Box base	1
23	39085200611S023	steering wheel	2
24	39085200611S024	bolt	16
25	39085200611S025	Trim panel	2
26	39085200611S026	bolt	6
27	39085200611S027	Directional wheel	2
28	39085200611S028	Battery mounting plate	1
29	39085200611S029	Battery positive wire	1
30	39085200611S030	Nut	4
31	39085200611S031	bolt	2
32	39085200611S032	Battery	1
33	39085200611S033	bolt	4
34	39085200611S034	L type bolt	2
35	39085200611S035	Battery negative wire	1
36	39085200611S036	Battery pressure plate	1
37	39085200611S037	Rear air deflector	1
38	39085200611S038	bolt	2
39	39085200611S039	bolt	1
40	39085200611S040	Wind channel	1
41	39085200611S041	bolt	6
42	39085200611S042	bolt	2
43	39085200611S043	Bellows	1
44	39085200611S044	Wind channel cover	1
45	39085200611S045	bolt	9
46	39085200611S046	Hinge	6

47	39085200611S047	bolt	24
48	39085200611S048	Air duct support plate	1
49	39085200611S049	Nut	2
50	39085200611S050	Muffler gasket	1
51	39085200611S051	Front wind deflector	1
52	39085200611S052	silencer-2	1
53	39085200611S053	bolt	4
54	39085200611S054	bolt	2
55	39085200611S055	Muffler gasket	1
56	39085200611S056	bolt	2
57	39085200611S057	silencer-1	1
58	39085200611S058	Nut	2
59	39085200611S059	Muffler gasket	1
60	39085200611S060	bolt	12
61	39085200611S061	door plank-1	1
62	39085200611S062	bolt	8
63	39085200611S063	Door lock	1
64	39085200611S064	Muffler mounting chamber	1
65	39085200611S065	A.V.R.	1
66	39085200611S066	bolt	2
67	39085200611S067	bolt	2
68	39085200611S068	A.V.R. Mounting plate	1
69	39085200611S069	Fuel tank	1
69-1	39085200611S0691	Fuel tank cap	1
69-2	39085200611S0692	Fuel level gauge	1
69-3	39085200611S0693	/	/
69-4	39085200611S0694	Fuel tank cavity	1
70	39085200611S070	Damping washer	1
71	39085200611S071	bolt	2
72	39085200611S072	bolt	4
73	39085200611S073	Fuel tank gasket	4
74	39085200611S074	/	/
75	39085200611S075	Fuel return pipe	0.6m
76	39085200611S076	Clamp	2
77	39085200611S077	Clamp	1
78	39085200611S078	Diesel filter	1
79	39085200611S079	Fuel inlet pipe	0.3m
80	39085200611S080	Clamp	3
81	39085200611S081	Oil tank lug-1	1
82	39085200611S082	Oil tank lug-2	1
83	39085200611S083	Muffler side plate	1
84	39085200611S084	Top cover	1
85	39085200611S085	door plank-2	1
86	39085200611S086	Axial fan	1
87	39085200611S087	Power side panel	4
88	39085200611S088	Control panel assembly	1
89	39085200611S089	bolt	6
90	39085200611S090	bolt	2
91	39085200611S091	Wiring board assembly	1
92	39085200611S092	bolt	3

93	39085200611S093	Carbon brush	1
94	39085200611S094	Hydraulic ejector rod	1