



Welding inverter **WME m 250**



STANDARD EQUIPMENT:

- welding cable
- return cable
- mask & brush

No	Order code	Description	Quantity
1	0302503503S001	handle	1
2	0302503503S002	shell	1
3	0302503503S003	Clamping plate	2
4	0302503503S004	main control board	1
5	0302503503S005	mounting plate	1
6	0302503503S006	Power board insulation board	1
7	0302503503S007	Welding mode switch harness	1
8	0302503503S008	digital display	1
9	0302503503S009	Overheat Indicator Harness	1
10	0302503503S010	Welding Potentiometer Harness	1
11	0302503503S011	potentiometer knob	2
12	0302503503S012	Potentiometer Harness	1
13	0302503503S013	Left and right wind deflectors	2
14	0302503503S014	Positive busbar	1
15	0302503503S015	quick socket	2
16	0302503503S016	plastic panel	1
17	0302503503S017	output fixing plate	1
18	0302503503S018	machine foot	4
19	0302503503S019	bottom back plate	1
20	0302503503S020	Rectifier board insulation board	1
21	0302503503S021	Negative busbar	1
22	0302503503S022	rectifier plate	1
23	0302503503S023	Power Board	1
24	0302503503S024	Inverter board radiator assembly	1
25	0302503503S025	Fan wiring harness	1
26	0302503503S026	Universal transfer switch	1
27	0302503503S027	External force cable gland	1
28	0302503503S028	Power cord harness	1
29	0302503503S029	Filter fixing plate	1
30	0302503503S030	filter	1

